

Test and Place Badge on Lo-Glow

Turn on your lights (parking or head lights) and make sure your wiring connections are secure. The Lo-Glow should be on at this point.

Remove the adhesive backing from the front of the Lo-Glow.

Place the OEM badge you have prepared onto the Lo-Glow. Make sure the badge is level and centered.

Re-attach any light housing you removed during the connection to the vehicle's wire harness.

Make sure all wires are tucked away and secure. Do not allow wires to rest on any sharp edges as this will cause a short in the future.



www.lo-glow.com



email : sales@supportmanufacturing.com



www.SupportManufacturing.com